


[Please notice!]

Please refer startup guide and transmitter manual together.

Preparation for using EX-LDT.

1.Remove the master unit from Grip unit.




※Please turn off the Power switch.

You can not remove unit when turn on the power.


- ① Pull up the lever on the back of the Master unit.
- ② While pressing the release button,
- ③ Pull it out in the direction of the arrow.
※ Return the lever on the back of the Master unit.

2.Please attach the steering unit.



- ① While pressing the release button,
- ② Push down the lock lever.
- ③ Attach the Steering unit.
- ④ Please return the lock lever.

3.Attach the master unit.






- ① Push it all the way in so that there is no gap between the grip protrusion and the master.



※The power switch cannot be operated unless it is pushed in enough.
Check that the power switch can be operated after mounting.

※Throttle Reverse Setting※



NORM ⇔ REVS